


UPCS-5 Configuration - Version C2



The 5 scene plate has 3 user settings:-
Backlight brightness 1 to 15 - Scene selected brightness 1 to 15 - Zone Number 1 to 16

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
B1	X		X		X		X		X		X		X		X	
B2		X	X			X	X			X	X			X	X	
B3				X	X	X	X					X	X	X	X	
B4								X	X	X	X	X	X	X	X	

View settings

- Step 1. **Press and Hold the Off button** - Releasing the Off button ends the setup procedure.
- Step 2a. Scene selected brightness - Press Raise button Read LED Status
- Step 2b. Backlight level - Press Lower button Read LED Status
- Step 2c. Zone number - Press Raise & Lower button Read LED Status
- . Compare the LED status indications on buttons 1 to 4 to the table above.
- Step 3. **Release Off button to exit setup**

Set Backlight and Scene Selected Brightness

- Step 1. **Press and Hold the Off button** - plus - Raise (Scene Selected) or Lower (Backlight)
- Step 2. Release the Raise or Lower button - NOT the Off button - all Leds will turn off
- Step 3. From the table above - press buttons individually in sequence - for the level required
- Step 4. **Release Off button to exit setup** - the required level is stored in memory

Set Zone number

- Step 1. Unclip front face plate.
- Step 2. Set Mode switch M=ON. - LED's will display current Zone as per table
- Step 3. If Zone number is correct - Go to Step 5.
- Step 4. To set/change Zone number - From the table above - press buttons individually in sequence - for the Zone number required - If you make a mistake tap the Off button to clear and start again.
- Step 4. To store the new Zone Number - Press and hold the Off button until all 4 LED's start flashing approx 3 seconds.
- Step 5. Set Mode switch M=OFF - re-fit front face plate

THE TOTAL SOLUTION


Quantran Systems Limited, Unit 6, Garnett Close, Greycaine Estate, Watford, Herts. WD24 7GN, UK.

Tel: +(0)1923 252512 Fax: +(0)1923 239559 web: www.quantran.com email: sales@quantran.com

UPCS5-C2/241011

Quantran Systems Limited is a **LEVITON** Company - **MIDDLE EAST, FAR EAST & ASIA**
REGIONAL HEADQUARTERS Jebel Ali Free Zone, View 19, Office 701, Dubai, UAE. Tel: +971 4 886 4722
Leviton Lighting & Energy Solutions, 20497 SW Teton Avenue, Tualatin, OR 97062, USA. t: +1 503.404.5500 f: +1 503.404.5594

UPCS-9 Configuration - Version C2



The 9 scene plate has 3 user settings:-
Backlight brightness 1 to 15 - Scene selected brightness 1 to 15 - Zone Number 1 to 16

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
B1	X		X		X		X		X		X		X		X	
B2		X	X			X	X			X	X			X	X	
B3				X	X	X	X					X	X	X	X	
B4								X	X	X	X	X	X	X	X	

View settings

- Step 1. **Press and Hold the Off button** - Releasing the Off button ends the setup procedure.
- Step 2a. Scene selected brightness - Press Raise button Read LED Status
- Step 2b. Backlight level - Press Lower button Read LED Status
- Step 2c. Zone number - Press Raise & Lower button Read LED Status
- . Compare the LED status indications on buttons 1 to 4 to the table above.
- Step 3. **Release Off button to exit setup**

Set Backlight and Scene Selected Brightness

- Step 1. **Press and Hold the Off button** - plus - Raise (Scene Selected) or Lower (Backlight)
- Step 2. Release the Raise or Lower button - NOT the Off button - all Leds will turn off
- Step 3. From the table above - press buttons individually in sequence - for the level required
- Step 4. **Release Off button to exit setup** - the required level is stored in memory

Set Zone number

- Step 1. **Press and Hold the Off button until Step 5** - Then press Raise & Lower button
- Step 2. Release Raise & Lower (**NOT the Off button**).LED's will display Zone as per table
- Step 3. If Zone number is correct - Go to Step 5.
- Step 4. To set/change Zone number - From the table above - press buttons individually in sequence - for the Zone number required - If you make a mistake tap the Off button to clear and start again.
- Step 5. To store the new Zone Number - Press and hold the Raise & Lower button until all 4 LED's start flashing approx 3 seconds.
- Step 5. Release all buttons - Zone number is now stored in memory

THE TOTAL SOLUTION

Quantran Systems Limited, Unit 6, Garnett Close, Greycaine Estate, Watford, Herts. WD24 7GN, UK.

Tel: +(0)1923 252512 Fax: +(0)1923 239559 web: www.quantran.com email: sales@quantran.com

UPCS9-C2/241011

Quantran Systems Limited is a **LEVITON** Company - **MIDDLE EAST, FAR EAST & ASIA**
REGIONAL HEADQUARTERS Jebel Ali Free Zone, View 19, Office 701, Dubai, UAE. Tel: +971 4 886 4722
Leviton Lighting & Energy Solutions, 20497 SW Teton Avenue, Tualatin, OR 97062, USA. t: +1 503.404.5500 f: +1 503.404.5594

UPCS-5 & 9 Configuration - Version C3

UPCS plates version 2 & 3 have the same cover plates so they are identical to look at
To determine the version number.

- Press & hold the OFF button
- Whilst holding the OFF button pressed
- Press and release also the RAISE button
LED's will illuminate on the 3 selection buttons indicating the plate number
Whilst still holding the OFF button
- Press & release any illuminated button
 - If the LED stays illuminated the plate is version 2
 - If the LED extinguishes the plate is version 3 - The button will toggle the LED ON/OFF



Fault indications

There are 2 types of fault indications.

- Led 2 & 3 flashing, indicates that the plate has power but is not detecting a valid data bus.
- Led 2 flashing, indicates that the plate is receiving data from a valid data bus but is not Receiving a led update for the current zone.

Notes

- All levels are displayed in binary on led 1-4, the following table converts from binary to level

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
B1	X		X		X		X		X		X		X		X	
B2		X	X			X	X			X	X			X	X	
B3				X	X	X	X					X	X	X	X	
B4								X	X	X	X	X	X	X	X	

Led brightness and backlight brightness can be set from 1 to 15
Zone can be set from 0 15 on SBus and 0 8 on MBus

- When setting levels buttons act as toggle

THE TOTAL SOLUTION

Quantran Systems Limited, Unit 6, Garnett Close, Greycaine Estate, Watford, Herts. WD24 7GN, UK.


Tel: +(0)1923 252512 Fax: +(0)1923 239559 web: www.quantran.com email: sales@quantran.com

UPCS-C31/241011

Quantran Systems Limited is a **LEVITON** Company - **MIDDLE EAST, FAR EAST & ASIA**
REGIONAL HEADQUARTERS Jebel Ali Free Zone, View 19, Office 701, Dubai, UAE. Tel: +971 4 886 4722
Leviton Lighting & Energy Solutions, 20497 SW Teton Avenue, Tualatin, OR 97062, USA. t: +1 503.404.5500 f: +1 503.404.5594

UPCS-5 & 9

Configuration - Version C3



1 - Setting the Zone

1. If fitted remove cover plate
- 2a. 9 Scene Plate - use a small screwdriver to press and hold the mode button, DO NOT release mode button until you have finished setting the zone.
- 2b. 5 Scene Plate - mode switch on and leave on until zone setting is finished. The current zone settings are now shown on buttons 1 to 4. If no leds are set then zone - on SBus = 16 on Mbus. = Master
3. If you want to change the zone setting do so now by pressing buttons 1 to 4.
4. To store any change - press and hold the Off button until leds flash (approx 2 seconds)
- 5a. 9 scene plate - release the mode switch.
- 5b. 5 scene plate - turn the mode switch Off.

2 - Viewing current plate settings

1. Led brightness can be viewed and changed without taking the front plate off, the Zone can be viewed but not changed unless you follow the previous set of instructions.
2. Press and hold the off button.

A) Led brightness

Press the raise button, Led brightness is now shown on leds 1-4, to change the brightness Release the raise button while keeping the off button pressed, tap in the new level then release the off button.

B) Backlight brightness

Press the lower button, backlight brightness is now shown on leds 1-4, to change the brightness release the lower button while keeping the off button pressed, tap in the new level then release the off button.

C) Zone Setting

Press both the raise and lower button, the zone setting is now show on leds 1-4, You cannot change the Zone setting from here.

THE TOTAL SOLUTION

Quantran Systems Limited, Unit 6, Garnett Close, Greycaine Estate, Watford, Herts. WD24 7GN, UK.

Tel: +(0)1923 252512 Fax: +(0)1923 239559 web: www.quantran.com email: sales@quantran.com

UPCS-C32/241011

Quantran Systems Limited is a **LEVITON** Company - **MIDDLE EAST, FAR EAST & ASIA**
REGIONAL HEADQUARTERS Jebel Ali Free Zone, View 19, Office 701, Dubai, UAE. Tel: +971 4 886 4722
Leviton Lighting & Energy Solutions, 20497 SW Teton Avenue, Tualatin, OR 97062, USA. t: +1 503.404.5500 f: +1 503.404.5594